Minicom - Connecting to your board

- Install minicom
- > sudo apt-get install minicom
- Connect board to USB port
- Determine port using dmesg
- > dmesg

[13289.017517] usb 2-1: ch341-uart converter now attached to ttyUSB0

- Allow regular user access to USB port > sudo chmod 0666 /dev/ttyUSB0
- Configure minicom and save as default (dfl) > sudo minicom -s
- · Connect to board
- > sudo minicom