

Printer - Samsung Xpress SL-C410W Color Laser Printer

- [Parts](#)
- [Fixes](#)
 - [Streaks on Page Running Vertical](#)
- [References](#)



Parts

Part #	Description
CLT-K406S	Black Toner Cartridge
CLT-C406S	Cyan Toner Cartridge
CLT-Y406S	Yellow Toner Cartridge
CLT-M406S	Magenta Toner Cartridge

Fixes

Streaks on Page Running Vertical

Cause:

Build up on blade of printer cartridge. You should notice build up of toner around the position of the streaks.

Solution:

Replace cartridge or remove blade and attempt to clean.

References

Reference	URL
Samsung Xpress SL-C410W Color Laser Printer	https://support.hp.com/us-en/product/samsung-xpress-sl-c410-color-laser-printer-series/17157201/model/17157203

Easy Fix For Dirty Prints on Samsung Printers By Cleaning or Replacing the Transfer Belt	https://www.youtube.com/watch?v=k2Fr7RRgKE
How to remove and clean Samsung Transfer Belt CLP-365	https://www.youtube.com/watch?v=SqsAnlePCOU&t=214s